

Storm door installation



- Remove door from packaging.
- Open hardware kit
- Measure inside brickmold width to confirm the door width matches.
- Measure inside brickmold measure height and transfer opening size to storm door (figure 1-2)
- Remove sweep from bottom of door and set aside for use later
- Cut both z bar at bottom to match above measurement (see figure 3)
- Lift door into opening. Open door to expose hinges. Use 12 x 1 1/2" long tap head screws to secure door hinges to brickmold (figure 4)
- Install 14 x 1 1/4" pan head z-bar screws into exterior holes, being careful to adjust space between door and z-bar to a gap of 1/8"(figure 5)
- Install sweep onto bottom of door and install 2 x 3/4" pan head screws into sweep slots. NOTE: if sweep rubber does not contact bottom sill, move down sweep as required, or remove rubber from slot and re-position(3 slots to choose from) Lubricate rubber to ease reapplication into slots (figure 6)
- Basic door installation is complete.
- Locate hardware kit and remove and follow installation instructions for the closing pump, safety chain, and the handle assembly.

Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Glass Removal

- To remove glass slide operating glass sash to the center position on the door.
- Force glass sash towards the spring track while pulling the opposite end of the sash out of the fixed track on the opposite side. Sash is now free (Figure 1)
- To remove the screen sash again force the screen sash into the spring track while pushing opposite corner towards exterior (Figure 2)

Caution: Removing screen will allow upper sash to slide down if unsupported. Use caution and have another person hold the upper sash into position until screen is reinstalled. Failure to follow this action can result in damage to the door unit and/or personal injury.

- To reinstall screen force upper glass into top track as far a possible
- Place screen sash back into opening being careful to place screen sash with small lip towards the fixed glass sash. Force screen sash into spring track until opposite side has cleared the frame and can position back into the fixed track



Questions call 1-800-565-0046

Figure 1



Figure 2

